

PED200 Assembly Instructions



Pedestal Contents:



Top



Base



Hardware



Post and Spike

Assembly Procedure:

Step 1: Mount spike to base protruding down using two screws, lock washers and nuts. Mount the post to the base pointing up using two screws, lock washers and nuts.

Step 2: Dig a hole approximately eight inches deep. Install the base so that cables enter the pedestal base. Fill the bottom of the pedestal with desired substrate.

Step 3: Install top of pedestal and lock using PA1900 or equivalent wrench.



1390 Aspen Way • Vista, CA 92081 • USA
800-642-2155 • FAX: 760-598-9263
Latin America: 760-510-0558
An ISO 9001 Company



PA1900 Can Wrench

